Philips
Cassette head cleaner

SAC2505W

Cleans cassette player

This cassette head cleaner uses non-abrasive cloth tape and special cleaning fluid to gently clean away dust, dirt and oxide build-up without damaging the audio heads and pinch rollers.

Maintain original sound quality
- Safe, wet cleaning system

Easy to use
- Simple operation as easy as playing a tape

Protect your cassette player
- Special cleaning fluid removes dust, dirt and oxide build-up

PHILIPS
sense and simplicity

Specifications

Packaging dimensions
- Packaging dimensions (W x H x D): 4.25 x 7.75 x .75 inch
- Nett weight: .17 lb
- Gross weight: .18 lb
- Tare weight: .01 lb

Outer Carton
- Outer carton (L x W x H): 4.75 x 4.75 x 8.5 inch
- Nett weight: 1.02 lb
- Gross weight: 2.381 lb
- Tare weight: 1.361 lb

Highlights

Special cleaning fluid
This cleaning fluid is specially formulated to gently clean away dirt, dust and oxide build-up. Works with the non-abrasive cloth tape.

Simple operation
Simple operation as easy as playing a tape. Just apply fluid and "play".

Wet cleaning system
Specially formulated cleaning fluid and non-abrasive cloth tape work together to thoroughly and safely clean away dust, dirt and oxide build-up.

Issue date 2009-11-06

Version: 1.1.2

12 NC: 8670 000 34791
UPC: 6 09585 14456 9

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com